The Receive light on my modem is blinking

Internet Troubleshooting & FAQs · https://www.bluestreamfiber.com/support/the-receive-light-on-my-modem-is-blinking/

The receive light on your modem should be steady and indicates the downstream signal has been confirmed. If the receive light is blinking it indicates a problem.

- Check all the cables and make sure they are secure.
- Unplug the power cord from the modem, wait 30 seconds, then plug it back in.
- Wait for the power, send, receive, and online lights to go steady.